



**LONG-WEARING LIPGLOSS WITH JOJOBA GLAZE® – EV**

Transfer resistant lipgloss containing **JOJOBA GLAZE® - EV** to prolong wear time and enhance gloss.

<b>INCI NAME</b>	<b>TRADE NAME</b>	<b>WT. %</b>
<b>Phase A</b>		
<b>Simmondsia Chinensis (Jojoba) Seed Oil (and)</b>	<b>JOJOBA GLAZE® – EV <sup>1</sup></b>	<b>25.00</b>
<b>Ethylene/Propylene/Styrene Copolymer (and)</b>		
<b>Butylene/Ethylene/Styrene Copolymer</b>		
Polybutene	Parapol 950 <sup>2</sup>	17.50
Hydrogenated Polyisobutene	Sophim	6.50
Glyceryle Hydrogenated Rosinate	Endere S <sup>3</sup>	3.50
Euphorbia Cerifera (Candelilla) Wax	Candelilla Wax SP75	4.80
Tridecyl Timellitate	Pelemol TDTM	13.45
Tocopheryl Acetate	Vitamin E Acetate	1.00
Microcrystalline Wax	Microwax 1275W <sup>4</sup>	4.80
Microcrystalline Wax	Multiwax 180W <sup>4</sup>	1.80
Octyl Methoxycinnamate	Eusolex 2292 <sup>5</sup>	7.50
C12-15 Alkyl Benzoate	Finsolv TN <sup>6</sup>	10.00
BHT	BHT <sup>7</sup>	0.05
Propylparaben	Propylparaben <sup>7</sup>	0.10
<b>Phase B</b>		
Red 28 Lake	C14-6623 D&C Red 28 Al Lake	0.75
Yellow 5 Lake	C69-4424 FC&C Yellow 5 Al Lake	0.20
Blue 1 Lake	C39-4433 FC&C Blue 1 Al Lake	0.05
<b>Phase B</b>		
Flavor	Watermelon Flavor #352-085 <sup>8</sup>	3.00
		100.00

**Procedure**

Heat phase A to 95-100C while stirring until the solids are melted. Rollermill phase B into a portion of phase A, then add to remaining phase A. Add phase C to phase A with lightening. Mix until homogeneous. Cool to 40C while propeller mixing, scraping sides occasionally, then fill.

**Suppliers**

<sup>1</sup> Desert Whale Jojoba Co.

<sup>2</sup> S&S Chemical

<sup>3</sup> Hercules

<sup>4</sup> Ross

<sup>5</sup> EM Industries

<sup>6</sup> Finetex

<sup>7</sup> Ruger

<sup>8</sup> Flavormatics

**~ DISPERSION ~ GLOSS ENHANCING ~**

JOJOBA GLAZE® is a registered trademark of Desert Whale Jojoba Company, Inc.

This information is based on our present state of knowledge. No warranty is expressed or implied as to the use or application of this product. The suitability and safety of the final formulation should be confirmed in all respects by appropriate evaluation.